

continued from page

Background


Surface Tension: Tendency of liquid's surfaces at rest to shrink to the minimum surface area. We define this

$$\gamma \propto \frac{F}{L} \quad \begin{array}{l} \leftarrow \text{force} \\ \leftarrow \text{length} \end{array} \quad (1)$$

viscosity: Resistance of a fluid to deformation at a given rate.


We can then say that:

Regime 1



Surface Tension

Regime 2



viscosity

$$\left(\frac{\gamma}{\rho}\right)^{1/3} \tau^{2/3} = \gamma_{\min} = \left(\frac{\gamma}{\eta}\right) \tau$$

Notice that both of these are of the form

$$\gamma_{\min} = C_0 \tau^\alpha \quad \leftarrow \text{Important!}$$

where C_0 & α are tunable parameters that we can get through fitting.

continued to page

Signature

Witnessed And Understood By

Date


Date

22.10.21

PROPRIETARY
INFORMATION

23

Diagram of Setup



EXPERIMENTAL SETUP

DATA COLLECTION

Setup No 1: Low Frame rate

Resolution : 336×240 px
 FPS : 1594.3 fps
 Exp : 57.77 ms

PUT IN GOOGLE
 DRIVE FOLDER
 NAMED "DROP PINCH
 LAB - PHYS 21101"

Recorded files :

dpo-1
 dpo-2
 dpo-3
 dpo-4
 dpo-5

Too far
 out -
 no
 regime 2.

reduce
 aperture for
 increased
 resolution

INCREASED VISCOSITY
 FOR NEXT TIME.

continued to page

Signature

Date

22.10.21

Witnessed And Understood By

Date

PROPRIETARY
 INFORMATION

continued from page

23

Setup No. 2: High Frame Rate

Resolution : 1920 x 960 px
 FPS : 38565 fpo
 EXP : 25.93 no
 GAIN : 0.28

Min Period: 20.98

filenames

UPLOAD TO
GOOGLE DRIVE

dpo-6

dpo-7, dpo-7-regime1

dpo-8

dpo-9, dpo-9-regime-2

dpo-10

dpo-11, dpo-11 R

Best for better regimes.

[END DAY 1]

ruler measurement

SAME SET UP INTO DAY 2, so recorded:

filenames

dpo-12

dpo-13

dpo-14

dpo-15

dpo-15 R

UPLOAD TO
GOOGLE DRIVE

converted to AVI using FFMpeg

ruler measurement

After review, it is clear that the best framing and resolution, also focus, is dpo-14. we will use this.

Signature

Date

23.10.21

Witnessed And Understood By

Date

continued to page

 PROPRIETARY
INFORMATION

Drop Pinch Lab

continued from page

24

Image analysiswe want 20 datapoints: $\frac{T_f - T_i}{\Delta t}$

to pinch off

$$\frac{5.23 - 0.92}{20} \approx \Delta t = 0.2$$

or 3 frames

pixels 2 meters: 164090
d p x 2m : 294360

dpo-15 R.AVI

UPLOAD TO
radii-min.xlsxBASED ON RESOLUTION
OF CAMERA

time (s)

dt (s)

radius (px)

dr (px)

	time (s)	dt (s)	radius (px)	dr (px)
1)	0.92	0.08	28.88	0.12
2)	1.15	0.08	27.75	0.12
3)	1.38	0.08	26.63	0.12
4)	1.62	0.08	25.00	0.12
5)	1.85	0.08	23.63	0.12
6)	2.08	0.08	22.13	0.12
7)	2.31	0.08	18.88	0.12
8)	2.54	0.08	17.88	0.12
9)	2.77	0.08	16.13	0.12
10)	3.00	0.08	14.16	0.12
11)	3.23	0.08	14.05	0.12
12)	3.46	0.08	11.72	0.12
13)	3.69	0.08	9.76	0.12
14)	3.92	0.08	7.55	0.12
15)	4.15	0.08	5.93	0.12
16)	4.38	0.08	3.93	0.12
17)	4.62	0.08	3.02	0.12
18)	4.69	0.08	1.87	0.12
19)	4.74	0.08	0.73	0.12
20)	5.23	0.08	0	0.12

continues

Date

Date

25.10.21

PROPRIETARY
INFORMATIONNOTE: dpx 2m taken as width of
marker on wheel.